STEREO IMPACT

Boom Suite On-Orbit Commissioning Procedure

IMPACT-BOOM-Comissioning_A.doc Version A – 2006-Jul-20

David Curtis, UCB IMPACT Project Manager
Date Run:
Observatory

Document Revision Record

Rev.	Date	Description of Change	Approved By
A	2006-Jul-20	Preliminary Draft	-

Distribution List

Dave Curtis, UCB Mario Acuna, GSFC Davin Larson, UCB

Table of Contents

Do	ocument Re	evision Record	i
Di	stribution l	List	i
1.	Overviev	<i>N</i>	1
	1.1.	Introduction	1
	1.2.	Document Conventions	1
	1.3.	Applicable Documents	1
2.	Test Setu	ıp	
	2.1.	Test Equipment	
	2.2.	Startup GSE	
	2.3.	Startup IDPU	
	2.4.	Startup MAG Heater	
3.		Sts	
	3.1.	Housekeeping Packet Contents and Commanding Test	
	3.1.1.	Verify Housekeeping Packet CCSDS Packet Header	
	3.1.2.	Verify Key Housekeeping Packet Contents	
	3.2.	C&DH Interface (1553) Test	
	3.2.1.	Telemetry	
	3.2.1.	Commands	
	3.2.2.	B Side Test	
	3.2.3. 3.2.4.	Spacecraft Status	
	3.2.4.	SWAVES Transfers	
	3.2.3.		
	3.4.	Memory Test	
		Watchdog Test	
	3.5.	Configuration	
4.		strument	
	4.1.	MAG Housekeeping	
	4.2.	MAG Data	
	4.3.	MAG Calibration Mode	
5.	-	SWEA/STE-D	
6.		Cest	
	6.1.	SWEA Housekeeping	
	6.2.	SWEA Test Pulser	
	6.3.	SWEA MCP Heater Test	
	6.4.	SWEA MCP Heater Adjust	
	6.5.	SWEA Door Open	
	6.5.1.	SWEA Door Open	
7.	STE-U /	STE-D Instrument	15
	7.1.	STE-U Housekeeping	
	7.2.	STE-D Housekeeping	
	7.3.	STE Adjustment	<i>16</i>
	7.4.	STE Bias Adjust	<i>17</i>
	7.5.	STE Threshold Adjust	<i>18</i>
	7.6.	STE Test Pulser	<i>18</i>
	7.7.	STE Door Source	<i>19</i>
	7.8.	STE Door Test:	<i>20</i>

7.8.1.	STE Door Open	20
	7.8.1.1 STE-U Door Open	20
	7.8.1.2 STE-D Door Open	21
7.8.2.	STE Door Close	22
	7.8.2.1 STE-U Door Close	22
	7.8.2.2 STE-D Door Close	22
7.8.3.	Final STE Door Open	23
	7.8.3.1 STE-U Door Open	23
	7.8.3.2 STE-D Door Open	23
7.8.4.	Final STE Configuration	24
8. SWEA	High Voltage Power On	25
8.1.	SWEA NRHV	
8.2.	SWEA V0	
8.3.	SWEA MCP HV	
8.3.1.	SWEA MCP HV Ramp Up	28

1. Overview

1.1. Introduction

The STEREO IMPACT Boom Suite consists of the Instrument Data Processing Unit (IDPU) plus the boom-mounted instruments (SWEA, STE-D, STE-U, and MAG). The IDPU if the single point interface between these instruments and the STEREO spacecraft for telemetry. The IDPU also interfaces to the SEP Suite and PLASTIC instruments. Commissioning for those instruments is described elsewhere. The IMPACT Boom deployment procedure is given in reference 3.

This document describes the Power on and Commissioning to be performed on the Boom Suite on orbit to ensure the hardware is performing correctly.

This proc should only be run when the spacecraft is in orbit.

1.2. Document Conventions

In this document, TBD (To Be Determined) means that no data currently exists. A value followed by TBR (To Be Resolved) means that this value is preliminary. In either case, the value is typically followed by a code such as UCB indicating who is responsible for providing the data, and a unique reference number.

Commands to be typed into the C&T GSE (stgsect) are indicated as follows: /SystemNOP. After typing the command hit the Enter key to send.

1.3. Applicable Documents

The following documents are closely interrelated with this specification. All documents can be found on the Berkeley STEREO/IMPACT FTP site unless otherwise indicated:

http://sprg.ssl.berkeley.edu/impact/dwc/

- 1. 7381-9012B (IMPACT/Spacecraft ICD, on the APL web page)
- 2. ICD/IMPACT CTM (command & telemetry database)
- 3. TestProcs/IMPACT-BOOM-DEPLOYMENT-A (boom deployment proc)

2. Test Setup

2.1

2.1. Test Equipment
1. IDPU Serial number
Configuration issues:
2. PROM version number:
3. EEPROM code version number:
4. Command & Telemetry GSE connected to spacecraft emulator via TCP/IP
C&T GSE version date
C&T Database version:, Date:
5. MAG Sensor (FM1, FM2):
6. STE-U Preamp/Sensor (FM1/FM2):
7. Boom harness (FM1/FM2)
8. SWEA/STE-D Sensor (FM1/FM2):
9. SWEA HV Enable Plug Type
10. SEP sensor (FM1/FM2):
11. PLASTIC sensor (FM1/FM2):
2.2. Startup GSE
1. Power up C&T GSE PC and start C&T GSE software (stgsect).
2. On the C&T GSE PC start up the SSH client and connect to the MOC (at
cho.jhuapl.edu; a profile should be set up to allow you to do that – see SSH.txt
if not). You will need a password.
3. Connect C&T GSE to the MOC – push the TCP/IP next to the TLM display on
the Received Data Panel:
Verify the TLM light comes on:
4. On the C&T GSE push the Record button. Determine the name of the
telemetry file

File Name:_____

2.3. Startup IDPU

	1.	Request the spacecraft TC power-on the IDPU. Record the bus voltage and
		IDPU current from the spacecraft displays
		Bus VoltageV
		IDPU CurrentmA
	2.	Verify C&T GSE is getting telemetry. On IDPU SOH panel, UTC time should
		correspond to time on Emulator PC (typically set to UTC), and should be
		incrementing every two seconds.
		Verify C&T GSE getting telemetry
	3.	After 10 seconds ISoftwareVersion should change to correspond to the
		EEPROM software version number. Verify no errors are reported and the version changes
		Record value of ISoftwareVersion
		Record value of IERRORCount
		Record value of IBootSelect
2.4.	St	artup MAG Heater
	1.	If the MAG heater is powered off, request the TC to power it on. Record the MAG Heater current from the spacecraft displays
		MAG Heater Supply CurrentmA
	2.	Record the MAG temperature on the C&T GSE:
		IMAGTempC
	3.	Record the telemetry MAG heater current (note that this is not expected to be an accurate measure of the actual current, but should correspond to the
		measurement made above to ~20%). The MAG heater will not come on above
		10C, but will take a ~5mA standby current.
		IMAGHeatermA

3. DCB Tests Record Start Time

3.1. Housekeeping Packet Contents and Commanding Test

Note the terms Housekeeping and State of Health (or SOH) are used interchangeably.

3.1.1. Verify Housekeeping Packet CCSDS Packet Header

 On the C&T GSE under the Main menu select ApID Display. This should bring up a hex packet display window. On that window select ApID 200 (housekeeping). Push clear. A new SOH packet should come up in a few seconds and be displayed in hex in the window

Verify_	
-	

• The first two bytes contain some fixed bit fields plus the ApID. They should be 00 0A

• The second two bytes contain the packet sequence counter, plus two fixed bits in the MSB. The data should be displayed LSByte first, and should increment by one with every new packet, every 2 seconds.

Verify		

• The third pair of bytes contains the packet size, which should contain the fixed value 09 01.

Verify		

• The next 6 bytes contain the packet collect time. This is decoded on the SOH display UTCs,f. This value should correspond to the time code provided by the spacecraft emulator (minus a few seconds of pipeline delay for the housekeeping packets). Verify the time corresponds to UTC, and that it increments by 2 seconds for every new packet

erif				

3.1.2. Verify Key Housekeeping Packet Contents

• ISampleTime – This is the instrument sample time counter. It displays in Hours:minutes:seconds, has a resolution of 1 second and a range of 16 hours (it jumps back to zero and start again every 16 hours). It starts at zero on reset. Verify it counts correctly.

Verify		
vernv		

• ISoftwareVersion – This is the code version number, which is fixed in the code. Record the value:

Value	

• IHardwareVersion – This is the FPGA version number, which is fixed in the hardware, and should equal 4.

Verify	

•	 IPollTimeMax, IPollTimeAvg – Monitor the IP 	ollTimeMax and	
	IPollTimeAvg values (on IDPU SOH panel) and	d record their maximum	
	values: IPollTin	meMax (<1s)	_ms
	IPollTime	eAvg (<.01s)	_ms
•	• ITimeJitter – this is a measurement of the maxim	mum jitter in the UTC tir	ne
	code provided over the 1553 interface. With the	e emulator this is usually	zero,
	and occasionally ~64us, the resolution of the 15	553 timing system. Recor	rd the
	maximum value seen:		
		Value (<1ms)	µs
•	• IErrorCode, IErrorData, IErrorCount – this is the	e error tracking values.	
	IErrorCode should be blank and IErrorCount sh	ould be zero.	
		Verify	
•	• Cause an error by sending an incorrect comman	d: /SystemFunction 100	. This
	should cause the IErrorCode to be "ERROR_C	mdBadFunction ", IErro	orData
	to be 100, and IErrorCount to be 1.		
		Verify	
•		Code should return to bla	ank
	and IErrorCount should return to zero.		
		Verify	
•	· · · · · · · · · · · · · · · · · ·	<u> </u>	
	IMPACT command verification system. ICom		
	commands since reset (modulo 65536), IComm	<u>-</u>	f the
	most recent IMPACT command received, and I		
	sequence number of the most recent IMPACT of	command received. Note	their
	values:		
		[CommandCount	
		CommandLastID	
		ommandLastSeq	
	Send the command /SystemNOP Note the i		
		CommandCount	
		CommandLastID	
	ICommandLastID should be SystemFunction .	ommandLastSeq	
	ICommandLastSeq should have incremented by		
	values:	one from their previous	
	varues.	Verify	
	Send a block of 100 commands: Start IMPA		
		[CommandCount	
		CommandLastID	
		ommandLastSeq	
	ICommandLastID should be SystemFunction .		
	ICommandLastSeq should have incremented by		
	values:	p 1000	
		Verify	
			_

3.2. **C&DH Interface (1553) Test**

3.2.1. Telemetry

Verify correct response to telemetry request. This is performed in step 2.3

3.2.2. Commands

Commands have been tested in previous steps (3.1).

3.2.3. B Side Test

Record which side of the 1553 bus is active.

• On the IDPU SOH panel of the C&T GSE, expand the ISCStatus byte. Record the value of the 1553A/-B bit:

1553A/-B	(A)·	
	111.	

3.2.4. Spacecraft Status

• The Emulator Spacecraft Status is set on the 1553/Spacecraft Status page. The value is displayed on the housekeeping SOH page under ISCStatus. Verify the value displayed corresponds to the spacecraft status.

Verify_	
Verify	
· <i>j</i> —	

3.2.5. SWAVES Transfers

• On the SOH display InterfaceActive value verify the SWAVES interface is Active. This indicates traffic to/from the SWAVES 1553 message buffers. If SWAVES is not powered on, the SWAVES Timeout bit should be set instead.

Verify	

3.3. Memory Test

The DCB has a built-in memory test. The system shuts down all other activity during this test, so there will be no commands or telemetry. It takes about 1 minute. When it comes back up it will restart as if from a reset, but it will report any memory errors it encountered in the error housekeeping.

• Send the command /IDPUMemoryTest 64 0. Wait for telemetry to resume and verify that no errors are reported.

Verify	
vernv	

3.4. Watchdog Test

• Verify loss of the timer tic interrupt causes a watchdog reset. Disable the timer interrupt by sending: /IDPUMemoryLoad 0x00 0x1F94 0x18. Verify

	the DCB resets after ~2 seconds and gives an ERROR_WatchdogReset error.
	Verify
3.5.	Configuration
	• Clear the error by sending / <i>ClearErrors</i> . IErrorCode should return to blank and IErrorCount should return to zero.
	Verify
	• Enable the instrument startup/shutdown sequences. <i>Start</i>
	IMPACTPowerSeqEnable. Verify the IDPU SOH CmdSeqEnable
	housekeeping shows sequences 0-5 and 8-11 enabled.
	Verify
	Record Completion Time

1.	MAG	G Instrument		
		Record Start Time_		
4.1.	MA	G Housekeeping		
	•	Verify on the C&T GSE InterfaceActive display that	the MAC	interface is
		active (1)	Verify	у
	•	Turn on the MAG SOH display on the C&T GSE. V in MAG SOH. Verify MAG command counter shoul ~5 seconds.	erify no r	ed/yellow limi
			Verify	У
	•	Verify nominal temperature for MAG sensor:	f + GT	
)
	•	If a GSE temperature sensor is available, record the GSE M.		o
.2.	MA	G Data		
	•	Enable the C&T GSE telemetry server. Start up the Mand connect to the C&T GSE. Verify that the connect	ction light	
	•	Enable the MAG Chart on the MAG GSE. If the value 1, sometimes 32768), send the command /MAGEnab out of saturation.		
			Verify	У
	•	Record the maximum RMS values.		_
		RMS X:	_Y:	Z:
4.3.	MA (G Calibration Mode Verify that the C&T GSE is recording data.		
		Ş	Verify	У
	•	Set the MAG sample rate to 32Hz: /SetMAGRate 1. come every ~1.5 seconds.		
			Verify	У
	•	Record the 1-packet average on the MAG sensor (AV	У	MAG GSE)
				Z
				e

•	• On the C&T GSE send the command /SetMagMode 0xC1 to turn on the MAG Calibration mode. Record the new 1-packet average:	
	-	X
		Y
		Z
		Range
•	• Verify that the measurement changed by +8500 c	counts +/-200 on each axis Verify
•	• Turn off the MAG Cal: send C&T GSE comman Verify that the 1-packet average returns to the or counts:	•
		Verify
•	 Use the Decom GSE to analyze the MAG data fill Record the characteristics of the turn-on of the C X Sample Time: Amplitude: Y Sample Time: Amplitude: Z Sample Time: Amplitude: 	al mode by the Decom GSE Rate: Rate:
•	• Use the Decom GSE to analyze the MAG data fit Record the characteristics of the turn-off of the C	
	X Sample Time: Amplitude:_	Rate:
	Y Sample Time: Amplitude:_	
	Z Sample Time: Amplitude:_	Rate:
•	• Set the MAG sample rate back to 8Hz: /SetMAG packets come every ~5 seconds.	Rate 4 . Verify telemetry
	1	Verify
	Record Completion Ti	me

5. Startup SWEA/STE-D

1.	Request the TC power-on the SWEA/STE-D service. Wait 10 seconds, ther	n
	record the current monitor on the spacecraft monitor	
	SWEA Currentm	nΑ
2.	Verify that on the C&T GSE ISCStatus display the SWEA Power display shows On (1), and on the Interface Active display, SWEAInterface shows active (1).	
	Verify	

6.	SWEA	A Test
		Record Start Time
6.1.	. SWEA	A Housekeeping
		Verify on the C&T GSE InterfaceActive display that the SWEA interface is ctive (1)
		Verify
	re	Furn on the SWEA/STE-D SOH display on the C&T GSE. Verify no ed/yellow limits, and the STE-D front end is powered on (AFEPWR on the SWEASTEDDig display = 1).
	_	Verify
	• R	Record the SWEA door position (SWEACOVSTAT under ISWEASTEUDig) Open/Closed
	• R	Record the SWEA HV Enables state (under ISWEASTEUDig)
		NRHVENB
		MCPHVENB
		Record the following SOH values from the C&T GSE SWEA/STE-D SOH anel.
	•	ISWEASTEDCur
		ISWEAMCPTemp
		ISWEADACTemp
	• If	f available, record the spacecraft-monitored SWEA temperature
		SWEA Temp
6.2.	. SWEA	A Test Pulser
	S	tart the STGSE-SWEA GSE (swea.exe). Enable the C&T GSE telemetry erver and connect the SWEA gse (TCP/IP button). Verify that the Connect ght comes on on the SWEA GSE.
		Verify
	tł	On the SWEA GSE turn on the 3D master and 3D numeric displays. Verify nat the UTC time code updates every 30 seconds, indicating 3D SWEA data lowing.
		Verify
		age through the 16 energies on the SWEA Numeric display and verify the D data is all zeros.
		Verify
	V	Furn on the SWEA test pulser using the command /SWEAPulserEnable. Verify that the ENBSWEATP bit comes on (1) in the ISWEASTEDDig isplay on the C&T GSE.
		Verify
	d	The SWEA test pulser should stimulate counts in all anodes, energies, and eflections. Counts should fall off with increasing energy (decreasing energy in number). Counts for different deflections should be about the same except

at the lowest energies (highest energy bin numbers). Counts should be highest for anodes 0 and 8, down a factor of ~2 for anodes 1 and 9, another factor of ~2 for anodes 2 and 10, etc. Using the 3D numeric and various graphic displays on the SWEA GSE verify this pattern. In particular verify counts in all anodes at least at low energies (high energy bin number).

Verify	
, 0111	

6.3. SWEA MCP Heater Test

The SWEA MCP heater is software controlled to a ground-set power level. The power is pulse-width modulated on a 20 second period, so operation of the heater can be verified by watching the current consumption on the SWEA primary 28V supply.

•	Set the SWEA MCP Heater to 10%: Send /SetSWEAMCPHeater 1. Verify
	that the SWEA primary power increases by ~90mA for 2 seconds out of every
	20 seconds.

• Record the SWEA MCP Temperature

ISWEAMCPTemp_____

• Set the SWEA MCP Heater to 100%: Send /SetSWEAMCPHeater 10. Verify that the SWEA primary power increases by ~90mA continuously.

Verify______

• Measure how long it takes the MCP to rise 2 degrees C from the starting

temperature recorded above.

Minutes

• Set the SWEA MCP Heater off. Send /SetSWEAMCPHeater 0. Verify that the SWEA primary power drops ~90mA and stays steady.

Verify_____

6.4. SWEA MCP Heater Adjust

• Monitor the SWEA MCP Temperature for a while (in parallel with other activities). Set the MCP heater to maintain an MCP temperature between -25 and +30C. Within this range a cooler temperature is desirable, but leave margin to cover low bus voltage cases. Use the command /SetSWEAMCPHeater to set the heater duty cycle between 0 and 10 (10=100%).

UTC Date/Time	Bus Voltage	Heater Setting	ISWEA MCP Temp	ISWEA DAC Temp	SWEA Temp (S/C)	ISTED Temp

6.5. SWEA Door Open

TO BE PERFORMED NO SOONER THAN L+1D

The SWEA door is actuated by a 1-time TiNi mechanism powered by an instrumentcontrolled circuit. Once opened the door cannot be re-closed. The door can only be opened if an appropriate enable connector is installed in SWEA-J2. The door must be opened in order to allow electrons to enter the instrument. While the door is open, the Microc

6.5.1. SWEA	Door O	pen
-------------	--------	-----

	anel Plate (MCP) detector is exposed to contamination.
SV	VEA Door Open
•	Verify that an appropriate enable plug is installed to allow the SWEA door to be activated.
	Enable Type
•	Verify that the SWEA instrument is powered on and generating telemetry (on the C&T GSE InterfaceActive display, SWEA interface is active (1)). Verify
•	Verify that the SWEA door state is closed (on the C&T GSE ISWEASTEDDig display, SWEACOVSTAT = CLOSED).
	Verify
•	Send the following two commands separated by no more than 15 seconds. /SWEACoverOper
	/SWEACoverOpen Verify no commanding errors reported on the C&T GSE
	Verify
•	Verify that the SWEA door state is open (on the C&T GSE ISWEASTEDDig display, SWEACOVSTAT = OPEN).
	Verify
	•

7. 3	STE-U / STE-D Instrument			
Record Start Time				
	e instrument is not in its default (power-on) mode, return GSE do:	rn it to that mode. On the		
	Start STENormalResLoad	Verify		
	• /SetSTEThreshold 0 12 12 12 12 12 12 12 12	Verify		
7.1.	STE-U Housekeeping			
	 Verify on the C&T GSE InterfaceActive display active (1) 	that the STE-U interface is Verify		
	• Turn on the STE-U SOH display on the C&T GS limits in STE-U SOH, and the STE-U front end the ISTEUDig display = 1).			
		Verify		
	 Verify the STE-U door position telemetry corres (STECOVSTAT under ISTEUDig) 			
		Open/Closed		
	 Record the following SOH values from the C&T 	GSE ISTE-U SOH panel. ISTEUCurmA		
		ISTEUTempC		
	IST	EUDACTempC		
	If available, record the spacecraft-monitored Boo			
	if a variable, record the spacecraft monitored Bo	Boom Temp		
		STE-U Temp		
7.2.	STE-D Housekeeping			
	• Verify on the C&T GSE InterfaceActive display active (1)	that the SWEA interface is		
		Verify		
	 Turn on the SWEA/STE-D SOH display on the red/yellow limits, and the STE-D front end is po 			
	ISWEASTEDDig display $= 1$).			
		Verify		
	 Verify the STE-D door position telemetry corres (STECOVSTAT under ISWEASTEUDig) 	ponds to the door position		
		Open/Closed		
	 Record the following SOH values from the C&T panel. 	GSE SWEA/STE-D SOH		
		WEASTEDCur		
		ISTEDTemp		
	ISW	EADACTemp		

	•	If available, record the spa	acecraft-mon		emperature EA Temp		
7.3.	STI	E Adjustment					
	•	Start the STGSE-STE GS and connect the STE gse (comes on on the STE GSI	(TCP/IP butte		•		
					Verify		
	•	Speed up the Monitor Rat /SetSTERateInt 2. Verify Rates Panel reads 2 secon	y the accumu				
		Rates I aliel leads 2 secon	us.		Verify		
	_	Sat the STE LUT for adiu	stmont: Con	d Stant STED			
	•	 Set the STE LUT for adjustment: Send <i>Start STEDoorLUT</i> Display the STE Rates panel and wait for it to update. Set to Rate 					
	•						
		it reads counts per accumi					
		GTELLD-10	LLD	ULD	RESET		
		STEU Det0					
		STEU Det1					
		STEU Det2					
		STEU Det3					
		STED Det0					
		STED Deto STED Det1					
		STED Det1					
		STED Det2 STED Det3					
		STED Det3					
	•	Enable the STE Spectra d update. Verify nominal S			wait for the display to		
		1 3		1	Verify		
					<i>J</i>		

7.4. STE Bias Adjust

•	Set to a lower threshold, ~1.5keV: /SetSTEThreshold 0 6 6 6 6 8 8 8 8. Verify
	STE rates are <10,000c/s (if not, adjust thresholds up).

Verify____

• Adjust STE-U bias voltage to optimize the spectra. The system performance will improve with bias voltage up to some value above which little improvement is seen. Set to the lowest voltage which achives good performance. Set the bias voltage with /SetSTEUBias commands. Default bias value is 22. Good performance typically requires ~100.

Bias	Det 0 LLD	Det 1 LLD	Det 2 LLD	Det 3 LLD

Adjust STE-D bias voltage to optimize the spectra. The system performance will improve with bias voltage up to some value above which little improvement is seen. Set to the lowest voltage which achives good performance. Set the bias voltage with /SetSTEDBias commands. Default bias value is 22. Good performance typically requires ~100.

Bias	Det 0 LLD	Det 1 LLD	Det 2 LLD	Det 3 LLD

7.5. STE Threshold Adjust

In the following steps adjust the STE thresholds with the command $\slashed{SetSTEThreshold} < n > < v >$, where <n> is the detector number (0-3 for STE-U, 4-7 for STE-D), and <v> is the desired value. You can set 4 thresholds at once with the command $\slashed{SetSTEThreshold} \ 0 < v0 > < v1 > < v2 > < v3 > < v4 > < v5 > < v6 > < v7 >$. The DAC settings are \sim 100eV per step, with the default value set to 12 (\sim 2keV).

Adjust the threshold for each detector while monitoring the Spectra and LLD rates. Find the lowest threshold value at which the Spectra count rate is < 10/sec (100/sample) in the lowest energy bin. Record the threshold setting and count rate below. From the spectra display note the lowest energy bin receiving counts.

Threshold	LLD	Energy Bin
	Threshold	Threshold LLD

7.6. STE Test Pulser

- Set to the default STE LUT. *Start STENormalResLoad*
- Enable the STE-U test pulser. Send command /STEUPulserEnable. Verify that the ENBSTETP bit comes on the ISTEUDig SOH display.

 Verify

•	Enable the STE-D test pulser. Send command /STEDPulserEnable. Verify
	that the ENBSTETP bit comes on the ISWEASTEDDig SOH display.
	Verify

• The test pulser in default mode ramps up in amplitude over an interval of 32 seconds, followed by 8 seconds of dead time before it starts again. Looking at the monitor rates you should see the LLDs firing at 2KHz for 32 out of each 40 seconds, dropping down to the background rate for the other 8 seconds. The reset rates should follow the same cycle, but the 2KHz counts shall be distributed amongst the resets. Turn on the Monitor Rates vs time plot, select a representative LLD, ULD, and RESET rate counter and run a few cycles. The ULD rates should see 2KHz for a short time in each 40-second interval, just before the LLD rates drop.

Verify	

	•	Set the STE binning mode to linear (with ~1.56keV resolution, mode 1). Send the command <i>Start STELinear</i> . Wait 1-2 minutes for the new LUT to load. On the STE GSE Spectra panel enable the Accumulate mode and accumulate a few test pulser cycles. Verify that the counts are spread evenly across the channels except the first few (below the LLD). Verify
	•	Set the test pulser to discrete amplitude mode. Send the command /SetSTEUCtrl 0x72F2 and /SetSTEUCtrl 0xF2F6. Wait ~40 seconds for a new test pulser cycle and reset the spectra accumulator. Verify that the counts now appear in ~7 discrete lumps, and the STE Mode ID indicates 1. Verify
	•	Increase the resolution of the display 4x (~0.39Kev/bin, mode 2). Start STEHiResCycle. This will use all 256 energy channels for one detector, cycling through the 4 detectors for 4 minutes each. In this mode the 4 curves on the spectra display that normally represent the 4 detectors now represent the four quarters of the spectra for the first detector. Verify that STE mode cycles through mode 2,3,4, and 5, returning to mode 0 at the end. Verify
	•	Disable the STE test pulser: send commands /STEUPulserDisable, /SetSTEUCtrl 0x70F0, /STEDPulserDisable and /SetSTEDCtrl 0xF0F4. Verify that the ENBSTETP bit goes off (0) on the ISTEUDig SOH display. Verify the spectra and monitor rates return to background levels. Verify
7.7.	STE	E Door Source
	•	Set the STE GSE Spectra display to accumulate, and accumulate a few minutes of data to get reasonable statistics on the STE door source. There should be peaks at 82keV from the Cd109 source and at 5keV from the Fe55 source. There will also be a number of florescence lines excited by the Cd109 source in the instrument.
	•	Start STEHiResCycle. This will use all 256 energy channels for one detector, cycling through the 4 detectors for 4 minutes each. In this mode the 4 curves on the spectra display that normally represent the 4 detectors now represent the four quarters of the spectra for the first detector. Verify that STE mode cycles through mode 2,3,4, and 5, returning to mode 0 at the end. Verify
	•	Set to hi res door monitor mode. <i>Start STEDoorLUT</i> . Wait 2 minutes and start an accumulation. Accumulate for at least 10 minutes. Verify

7.8. STE Door Test:

This proc test the STE-U and STE-D door open/closed proc. It assumes the door is closed to begin with.

7.8.1. S	ΓΕ Door Open
•	Verify that the Emulator Spacecraft Status has IDPU Power and Thruster Warnings OFF (they will inhibit opening of the STE door) Verify
•	
	STE-D TemperatureC
	Script:
7.8.1.1	STE-U Door Open
•	Record the state of the STE-U door housekeeping on the STEDoor SOH display. If ISTEUCovStat is not CLOSED skip this proc: ISTEUDoorCount ISTEUDoorStart ISTEUDoorDone ISTEUCovStat ISTEUCovSW
•	Command the door open. Send the command /STEUDoorOpen. Verify by inspection that the cover opens and no instrument error occurs: Verify
•	If the GSE indicates an STE AFE trip (STE housekeeping goes blue), send /STEUAFEOn
	Verify
•	Record the STEU Door housekeeping.
	ISTEUDoorCount
	ISTEUDoorStart ISTEUDoorDone
	ISTEUCovStat
	ISTEUCovSW
•	Verify that the DoorCount increases by 1, the start and done times are in limit
-	(not red/yellow), ISTEUCovStat is now OPEN, and ISTEUCovSW is now OFF.
	Verify

7.8.1.2 STE-D Door Open

•	Verify that the SWEA Enable plug in SWEA-J2 supports opening the STE-D Door.
	Verify
•	Record the state of the STE-D door housekeeping on the STEDoor SOH
	display. If ISTEDCovStat is not CLOSED skip this proc:
	ISTEDDoorCount
	ISTEDDoorStart
	ISTEDDoorDone
	ISTEDCovStat
	ISTEDCovSW
•	Command the door open. Send the command /STEDDoorOpen. Verify by inspection that the cover opens and no instrument error occurs:
	Verify
•	If the GSE indicates an STE AFE trip (STE housekeeping goes blue), send /STEDAFEOn
	Verify
•	Record the STED Door housekeeping.
	ISTEDDoorCount
	ISTEDDoorStart
	ISTEDDoorDone
	ISTEDCovStat
	ISTEDCovSW
•	Verify that the DoorCount increases by 1, the start and done times are in limit (not red/yellow), ISTEDCovStat is now OPEN, and ISTEDCovSW is now OFF.
	Verify

7.8.2. STE Door Close

Note that 2 minutes must elapse between door motions.

7.	8.2.1	1 S	ΓF-U	Door	· Close

7.8.2.1 S	TE-U Door Close
•	Command the door closed. Send the command /STEUDoorClose. Verify by inspection that the cover closes:
	Verify
•	If the GSE indicates an STE AFE trip (STE housekeeping goes blue), send /STEUAFEOn
	Verify
•	Record the STEU Door housekeeping.
	ISTEUDoorCount
	ISTEUDoorStart
	ISTEUDoorDone
	ISTEUCovStat
	ISTEUCovSW
•	Verify that the ISTEUDoorCount increases by 1, the start and done times are in limit (not red/yellow), ISTEUCovStat is now OPEN, and ISTEUCovSW is now OFF.
	Verify
	·———
7.8.2.2 S	STE-D Door Close
•	Command the door closed. Send the command /STEDDoorClose. Verify by
	inspection that the cover closes:
	Verify
•	If the GSE indicates an STE AFE trip (STE housekeeping goes blue), send /STEDAFEOn
	Verify
•	Record the STEU Door housekeeping.
	ISTEDDoorCount
	ISTEDDoorStart
	ISTEDDoorDone
	ISTEDCovStat
	ISTEDCovSW
•	Verify that the ISTEDDoorCount increases by 1, the start and done times are
·	in limit (not red/yellow), ISTEDCovStat is now OPEN, and ISTEDCovSW is now OFF.
	Verify

7.8.3. Final STE Door Open

Open the door one more time to achieve the final configuration. Note that 2 minutes must elapse between door motions.

7.8.3.1 STE-U Door O	pen
----------------------	-----

7.8.3.1 S	STE-U Door Open				
•	Record the state of the STE-U door housekeeping on the STEDoor SOH				
	display. If ISTEUCovStat is not CLOSED skip this proc:				
	ISTEUDoorCount				
	ISTEUDoorStart				
	ISTEUDoorDone				
	ISTEUCovStat				
	ISTEUCovSW				
•	Command the door open. Send the command /STEUDoorOpen. Verify by				
	inspection that the cover opens and no instrument error occurs:				
	Verify				
•	If the GSE indicates an STE AFE trip (STE housekeeping goes blue), send				
	/STEUAFEOn				
	Verify				
•	Record the STEU Door housekeeping.				
	ISTEUDoorCount				
	ISTEUDoorStart				
	ISTEUDoorDone				
	ISTEUCovStat				
	ISTEUCovSW				
•	Verify that the DoorCount increases by 1, the start and done times are in limit (not red/yellow), ISTEUCovStat is now OPEN, and ISTEUCovSW is now OFF.				
	Verify				
7022	PTE D Door Open				
1.8.3.2 8	STE-D Door Open				
•	Verify that the SWEA Enable plug in SWEA-J2 supports opening the STE-D Door.				
	Verify				
•	Record the state of the STE-D door housekeeping on the STEDoor SOH				
•	display. If ISTEDCovStat is not CLOSED skip this proc:				
	ISTEDDoorCount				
	ISTEDDoorStart				
	ISTEDDoorDone				
	ISTEDCovStat				
	ISTEDCovStat				
•	Command the door open. Send the command /STEDDoorOpen. Verify by				
•	inspection that the cover opens and no instrument error occurs:				
	Verify				
•	If the GSE indicates an STE AFE trip (STE housekeeping goes blue), send				
_	in the ODE indicates an DTE M E trip (DTE housekeeping goes orde), send				

/STEDAFEOn

	Verify
•	Record the STED Door housekeeping.
	ISTEDDoorCount
	ISTEDDoorStart
	ISTEDDoorDone
	ISTEDCovStat
	ISTEDCovSW
•	Verify that the DoorCount increases by 1, the start and done times are in limit (not red/yellow), ISTEDCovStat is now OPEN, and ISTEDCovSW is now OFF.
	Verify
7.8.4. Fin	al STE Configuration
•	Speed up the Monitor Rates accumulation interval to 10 seconds. Send /SetSTERateInt 10. Verify the accumulation interval as displayed on the STE Rates Panel reads 10 seconds:
	Verify
•	Set the STE LUT to normal: Send <i>Start STENormalResLoad</i> . Verify STEID returns to zero.
	Verify

8. SWEA High Voltage Power On

Record	Start Time	
NEUNI	Man Inne	

TO BE PERFORMED ON ORBIT, NO SOONER THAN 1 HOUR AFTER SWEA COVER OPEN, TO AVOID DAMAGE TO SWEA MCP

8.1. **SWEA NRHV**

The S analyz у a num the bei enable

er d ber o nch	A Non-Regulated High Voltage (NRHV) supply is used to generate the effector and sweep supply voltages. It operates at ~1500V, and is protected by of hardware and software protections against accidental turn-on. Generally on this supply is safe to be powered up. However, ensure that the MCP is not accept in vacuum.
•	Turn off the SWEA test pulser using the command /SWEAPulserDisable. Verify that the ENBSWEATP bit goes off (0) in the ISWEASTEDDig display on the C&T GSE.
	Verify
•	Verify the SWEA door has been open for at least 1 hour. If not, use 6.5 to open it.
	Verify
•	Verify a high voltage enable plug is installed in SWEA-J2.
	Enable Type
•	Enable NRHV by sending the following two commands separated by no more than 15 seconds.
	/SWEAArmNRHV /SWEANRHVOn
	Verify no commanding errors reported on the C&T GSE
	Verify
•	Verify that the SWEA NRHV state is On (on the C&T GSE ISWEASTEDDig display, NRHVENB = 1).
	Verify
•	Record the following high voltage values from the C&T GSE SWEA/STE-D Housekeeping display:
	ISWEANR5V
	ISWEAAnal
	ISWEADefl1
	ISWEADefl2
•	Send /SWEAFHKPAnal to request a readout of the analyzer HV waveform.
	Later use DECOM to display the waveform and append to this proc. Verify three ApID 214 packets are sent.
	Verify
•	Send /SWEAFHKPDef1 to request a readout of the Deflector 1 HV
	waveform. Later use DECOM to display the waveform and append to this proc. Verify three ApID 214 packets are sent.
	Verify

•	Send /SWEAFHKPDef2 to request a readout of the Deflector 1 HV
	waveform. Later use DECOM to display the waveform and append to this
	proc. Verify three ApID 214 packets are sent.

Verify

8.2. **SWEA VO**

V0 is a programmable voltage in the analyzer that effects the operation of the instrument.

• Set the software to allow manual control of V0. Send /SWEAManualV0. Verify the ISWEAAUTOV0 (bit 2) is off (0) in the IAUTOLUT display on the C&T GSE.

Verify		

• Send the following commands to set the V0 voltage and record the resulting values of ISWEAV0 in the SWEA/STE-D housekeeping display of the C&T GSE.

Command	Measured ISWEAV0	Nominal V0
	value	value
/SetSWEAManualV0 0xFF		-25 V
/SetSWEAManualV0 0x80		-12.5 V
/SetSWEAManualV0 0x00		0 V

8.3. **SWEA MCP HV**

TO BE PERFORMED ON ORBIT, NO SOONER THAN 1 HOUR AFTER SWEA COVER OPEN, TO AVOID DAMAGE TO SWEA MCP

•	• Verify the SWEA door has been open for at least 1 hour. If not, use 6.5 to open it.
	Verify
•	• Verify a high voltage enable plug or enable GSE in installed in SWEA-J2 Enable Type
•	 Enable MCPHV by sending the following two commands separated by no more than 15 seconds. /SWEAArmMCPHV /SWEAMCPHVOn
	Verify no commanding errors reported on the C&T GSE
	Verify
•	• Verify that the SWEA MCPHV state is On (on the C&T GSE ISWEASTEDDig display, MCPHVENB = 1).
	Verify
•	• Record the following high voltage value from the C&T GSE SWEA/STE-D Housekeeping display:
	ISWEAMCP (0V)
8.3.1.	SWEA MCP HV Ramp Up

Ramp the SWEA MCP HV up to its nominal level through a few steps. Record the indicated data at each step. Note that the IDPU will ramp the voltage up to the desired setting at ~100V/second. Wait for ramping to complete before taking the measurement.

Command	Nominal	Instrument	ISWEAMCP	Moment N
	Voltage	Current	(C&T GSE)	(SWEA
				GSE)
/SetSWEAMCP 0	0			
/SetSWEAMCP 36	500			
/SetSWEAMCP 73	1000			
/SetSWEAMCP 109	1500			
/SetSWEAMCP 146	2000			
/SetSWEAMCP 182	2500			
/SetSWEAMCP 190	2600			
/SetSWEAMCP 197	2700			
/SetSWEAMCP 201	2760			